





INSTRUCTION

Thank you for purchasing the spa/pool vacuum cleaner. The spa/pool vacuum cleaner is hand held rechargeable cleaner which is easy to use. It saves water and reduces chemical consumption in the cleaning process. It is suitable for most spa and above-ground pools. Please note that the outlet hole of the lower body (the right photo) must be submerged during operation to avoid damage to the pump. It is designed to collect floor and seat debris - it is not a surface skimming device.

The product is powered by 1600mAh rechargeable lithium polymer batteries. It takes about 2 hours to charge full electricity, use for about 2 hours after full charged. The charger used in this product is AC 100V-240V / ~50/60HZ output 12.6 V 1000mA.




Cleaners comes with parts as below




When found no electricity, please confirm whether the cleaner is fully charged or long time no using.
When electricity is weak after a period of time, please charge it in time.

Four patterns



How to clean the filter



GENERAL MAINTENANCE

To ensure longevity of your cleaner some basic maintenance is required.

1. Periodically check the machine whether there is electricity in the batteries to ensure that the product can work normally when used. If you don't use it for a long time, please charge cleaner once half a month to extend the battery life.
2. Rinse the cleaner off after use with fresh water to prevent chemical damage.
3. Ensure the filter is clean after each use.
4. Never leave out in direct sunlight.
5. When testing the cleaner never run the motor out of water.
6. Never take the pump apart without prior consultation with the manufacturer.

TROUBLE SHOOTING

When the cleaner doesn't work, please pay attention to the following solutions.

1. Please confirm whether the cleaner is fully charged or have no power because of long time no using. Please recharge it.
2. Every time you charge the cleaner, remember to cover the soft plug of the charging port. If it is more than half a month no using after full charged, please recharge the electricity once again before use.